


## Conexiones reusables para mangueras SAE 100 R1 y SAE 100 R2

### Macho fijo rosca NPT


#### C1101 - C2101



Nº CODIGO SAE 100 R1	Nº CODIGO SAE 100 R2	Manguera Ø Interno	TAMAÑO ROSCA
1101-03-02	2101-03-02	3/16"	1/8"-27
1101-03-04	2101-03-04	3/16"	1/4"-18
1101-04-02	2101-04-02	1/4"	1/8"-27
1101-04-04	2101-04-04	1/4"	1/4"-18
1101-05-06	2101-05-06	5/16"	3/8"-18
1101-06-06	2101-06-06	3/8"	3/8"-18
1101-06-08	2101-06-08	3/8"	1/2"-14
1101-08-08	2101-08-08	1/2"	1/2"-14
1101-10-12	2101-10-12	5/8"	3/4"-14
1101-12-12	2101-12-12	3/4"	3/4"-14
1101-16-16	2101-16-16	1"	1" -11 1/2
1101-20-20	2101-20-20	1 1/4"	1 1/4"-11 1/2
1101-24-24	2101-24-24	1 1/2"	1 1/2"-11 1/2
1101-32-32	2101-32-32	2"	2"-11 1/2

### Macho fijo rosca BSPT

#### C1102 - C2102



Nº CODIGO SAE 100 R1	Nº CODIGO SAE 100 R2	Manguera Ø Interno	TAMAÑO ROSCA
1102-03-02	2102-03-02	3/16"	1/8"-28
1102-03-04	2102-03-04	3/16"	1/4"-19
1102-04-02	2102-04-02	1/4"	1/8"-28
1102-04-04	2102-04-04	1/4"	1/4"-19
1102-05-06	2102-05-06	5/16"	3/8"-19
1102-06-06	2102-06-06	3/8"	3/8"-19
1102-06-08	2102-06-08	3/8"	1/2"-14
1102-08-08	2102-08-08	1/2"	1/2"-14
1102-10-12	2102-10-12	5/8"	3/4"-14
1102-12-12	2102-12-12	3/4"	3/4"-14
1102-16-16	2102-16-16	1"	1" -11
1102-20-20	2102-20-20	1 1/4"	1 1/4"-11
1102-24-24	2102-24-24	1 1/2"	1 1/2"-11
1102-32-32	2102-32-32	2"	2"-11

"Poberaj SA se reserva el derecho de modificar las características y medidas de sus productos sin previo aviso".